

00810-0177-4728  
Rev EA  
9/01



## **Models 644H and 644R Smart Temperature Transmitters**

**EN**

**ROSEMOUNT®**

  
**EMERSON**  
Process Management



## Model 644 Smart Temperature Transmitter

Model 644 Revision: 5.5.2, 5.5.3, 5.5.4  
HART® Communicator Field Device Revision:  
Dev v5, DD v2

### NOTICE

Read the complete product manual before installing, operating, or servicing the Models 644H and 644R Smart Temperature Transmitters. Failure to comply with safe transmitter installation and operating practices can cause severe injury or death.

The information contained in this abbreviated field manual is intended only as an aid for skilled users who possess complete product manuals and are already familiar with the installation and operation of the Models 644H and 644R Smart Temperature Transmitters.

Please contact your nearest Fisher-Rosemount location for additional information or assistance regarding safe installation and operation of the Models 644H and 644R Smart Temperature Transmitters.

**Rosemount Inc.**  
8200 Market Boulevard  
Chanhausen, MN 55317 USA  
Tel 1-800-999-9307  
Fax (952) 949-7001

**Rosemount Temperature GmbH**  
Frankenstrasse 21  
63791 Karlstein  
Germany  
Tel 49 (6188) 992-0  
Fax 49 (6188) 992-112

**Fisher-Rosemount**  
Singapore Pte Ltd.  
1 Pandan Crescent  
Singapore 128461  
Tel (65) 777-8211  
Fax 65 777-0947  
AP.RMT-Specialist@frco.com

© 2001 Rosemount, Inc.

*Rosemount® Models 644H and 644R Smart Temperature Transmitters may be protected by one or more U.S. Patents pending. Other international patents pending.*

*Rosemount and the Rosemount logotype are registered trademarks of Rosemount Inc.*

*HART is a registered trademark of the HART Communication Foundation.*

*Noryl and Lexan are registered trademarks of General Electric  
WAGO is a registered trademark of WAGO Kontakttechnik GmbH, Germany*

*Photo Cover: 644-644C904, 644C903, 644C905*



Fisher-Rosemount satisfies all obligations coming from legislation to harmonize product requirements in the European Union.



Fisher-Rosemount satisfies all obligations coming from

**ROSEMOUNT®**

**EMERSON**  
Process Management



---

## Table of Contents

### Section 1: Introduction

Safety Messages .....	1-1
Warnings .....	1-1
Transmitter Overview .....	1-2
Manual Overview .....	1-2
Considerations .....	1-3
General .....	1-3
Mechanical .....	1-3
Electrical .....	1-3
Environmental .....	1-3

### Section 2: Installation

Safety Messages .....	2-1
Tools needed for installation .....	2-3
Mounting .....	2-3
Special Mounting Considerations .....	2-3
Installation Procedures .....	2-4
Transmitter .....	2-4
Multichannel Installations .....	2-9
LCD Meter Installation .....	2-9
Field Wiring .....	2-10
Sensor connections .....	2-12
RTD or Ohm Inputs .....	2-12
Thermocouple or Millivolt Inputs .....	2-12
Failure Mode .....	2-13
Changing Switch Positions .....	2-13

### Section 3: Operation

Safety Messages .....	3-1
Power Supply .....	3-1
Surges and Transients .....	3-2
Configuration .....	3-2
Online Menu .....	3-2
Hart Fast Key Feature .....	3-2

---

**Section 4: Hardware and Software Maintenance and Troubleshooting**

Safety Message .....	4-1
Diagnostic Messages .....	4-1
Hardware .....	4-1
Model 275 HART Communicator .....	4-4
LCD Meter .....	4-7

**Appendix A: Reference Data**

Specifications .....	A-1
Functional .....	A-1
Performance .....	A-3
Dimensional Drawings .....	A-8
Ordering Information .....	A-11
Configuration .....	A-13
Standard .....	A-13
Custom .....	A-14
Tagging .....	A-14

**Appendix B: Hazardous Locations Certifications**

Safety Messages .....	B-1
Hazardous Locations Certifications .....	B-1
European ATEX Directive Information .....	B-4
Installation Drawings .....	B-5

**Appendix C: Model 644 and 244E Manual Supplement**

Old Transmitter .....	C-2
Transmitter Design .....	C-2
Sensor Wiring Diagrams .....	C-2
Special Mounting Considerations .....	C-3
New Transmitter .....	C-4
Transmitter Design .....	C-4
Sensor Wiring Diagrams .....	C-4
Special Mounting Considerations .....	C-5
HART Communicator (Model 644 only) .....	C-5
Specifications .....	C-6

Safety Messages .....	page 1-1
Transmitter Overview .....	page 1-2
Manual Overview .....	page 1-2
Considerations .....	page 1-3

## SAFETY MESSAGES

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Please refer to the following safety messages before performing an operation preceded by this symbol.

## Warnings

### ⚠ WARNING

#### Explosions could result in death or serious injury.

- Do not remove the connection head cover in explosive atmospheres when the circuit is live.
- Before connecting a HART-based communicator in an explosive atmosphere, make sure the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- All connection head covers must be fully engaged to meet explosion-proof requirements.

#### Process leaks could result in death or serious injury.

- Install and tighten thermowells and sensors before applying pressure
- Do not remove the thermowell while in operation.

#### Electrical shock could cause death or serious injury.

- Use extreme caution when making contact with the leads and terminals.
- Under certain fault conditions, high voltage may be present on transmitter leads and terminals.

---

## TRANSMITTER OVERVIEW

Thank you for choosing the Model 644 Smart Temperature Transmitter. Features of the Model 644 include:

- Accepts inputs from a wide variety of sensors
- Configuration using HART protocol
- Electronics that are completely encapsulated in epoxy and enclosed in a metal housing, making the transmitter extremely durable and ensuring long-term reliability
- A compact size and two housing options allowing mounting flexibility for the control room or the field

Rosemount Inc. has a full range of compatible connection heads, sensors, and thermowells to provide complete assemblies for process temperature measurements. Refer to Volume 1 of the Rosemount Temperature Sensors and Assemblies Product Data Sheet (document number 00813-0100-2654) for thread mount sensors and accessories. Refer to Volume 2 (document number 00813-0101-2654) for DIN-style sensors and accessories.

## MANUAL OVERVIEW

This manual is designed to assist in the installation, operation, and maintenance of Rosemount® Models 644H and 644R.

### Section 2: Installation

- Installation tools
- Mounting
- Installation
- Field wiring

### Section 3: Operation

- Power supply
- Configuration

### Section 4: Hardware and Software Maintenance and Troubleshooting

- Hardware maintenance
- Diagnostic messages

### Appendix A: Reference Data

- Specifications
- Dimensional drawings
- Ordering information



---

**Appendix B: Hazardous Locations Certifications**

- Hazardous locations certifications
- Installation drawings

**Appendix C: Model 644 and 244E Manual Supplement**

- Comparison between new and old Models 644 and 244E
- Specifications

## **CONSIDERATIONS**

### **General**

Electrical temperature sensors such as RTDs and thermocouples produce low-level signals proportional to their sensed temperature. The Model 644 converts the low-level sensor signal to a standard 4–20 mA signal that is relatively insensitive to lead length and electrical noise. This current signal is then transmitted to the control room via two wires.

### **Mechanical**

When choosing an installation location and position, take into account the need for access to the transmitter.

### **Wiring Connections**

Make wiring connections through the cable entry in the side of the connection head. Be sure to provide adequate clearance for cover removal.

### **Electrical**

Proper electrical installation is necessary to prevent errors due to sensor lead resistances and electrical noise. Shielded cable should be used in electrically noisy environments.

### **Environmental**

The transmitter electronics module is permanently sealed within the housing, resisting moisture and corrosive damage. Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.



**2****Installation**

---


Safety Messages .....	page 2-1
Tools needed for installation .....	page 2-3
Mounting .....	page 2-3
Installation Procedures .....	page 2-4
Field Wiring .....	page 2-10
Sensor connections .....	page 2-12
Failure Mode .....	page 2-13

---

**SAFETY MESSAGES**

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Please refer to the appropriate safety messages listed in “Warnings” on page 1-1 before performing an operation preceded by this symbol.

Figure 2-1. Installation Flowchart



244-244\_03A

TOOLS NEEDED FOR INSTALLATION

The tools needed for installation are as follows:

Models 644H and 644R	Model 275 HART Communicator
<ul style="list-style-type: none"><li>• Transmitter</li><li>• Mounting apparatus</li></ul>	<ul style="list-style-type: none"><li>• Hart communicator</li></ul>

MOUNTING

The Models 644H and 644R transmitters will operate within specifications for ambient temperatures between −40 and 185 °F (−40 and 85 °C).


Special Mounting Considerations

Special mounting hardware is available for mounting a Model 644H head mount transmitter to a DIN rail, or assembling a new Model 644H to an existing threaded sensor connection head (former option code L1).

Mounting a Model 644H to a DIN Rail

To attach a head mount transmitter to a DIN rail, assemble the appropriate rail mounting kit (part number 00644-5301-0010) to the transmitter as shown in Figure 2-2, then follow the procedure under “Rail Mount Transmitter with Integral Mount Sensor” on page 2-7.

Figure 2-2. Assembling Rail Clip Hardware to a Model 644H




644-5302B01A, D02A

### Retrofitting a Model 644H for Use in an Existing Threaded Sensor Connection Head

To mount a Model 644H in an existing threaded sensor connection head (former option code L1), order the Model 644H retrofit kit (part number 00644-5321-0010). The retrofit kit includes a new mounting bracket and all associated hardware necessary to facilitate the installation of the Model 644H in the existing head (see Figure 2-15).

Figure 2-3. Assembling Model 644H for Use in an Existing L1 Connection Head



644-5321A01A

## INSTALLATION PROCEDURES

### Transmitter

Installation consists of attaching a thermowell to the pipe or process container wall, assembling any necessary extensions, connection heads, or junction boxes, and making electrical connections. Refer to the appropriate procedure and the accompanying illustrations when installing the transmitter.


### Head Mount Transmitter with DIN Plate Style Sensor

Refer to Volume 2 of the Rosemount Sensors Product Data Sheet (document number 00813-0101-2654) for complete sensor and mounting accessory information.

To complete the assembly, follow the steps described below.

- ⚠ 1. Attach the thermowell to the pipe or process container wall. Install and tighten the thermowell before applying pressure.
2. Set the transmitter failure mode switch (see Figure 2-11 on page 2-11).
3. Assemble the transmitter to the sensor. Push the transmitter mounting screws through the sensor mounting plate and insert the snap rings (optional, part number 00644-4432-0001) into the groove of each transmitter mounting screw.
4. Insert the transmitter-sensor assembly into the connection head. Thread the transmitter mounting screw into the connection head mounting holes.
5. Assemble the extension to the connection head. Insert the assembly into the thermowell.
6. Attach a cable gland into the shielded cable.
7. Insert the shielded cable leads into the connection head through the cable entry. Connect and tighten the cable gland.
- ⚠ 8. Connect the shielded cable leads to the transmitter power terminals. Avoid contact with leads and terminals.
- ⚠ 9. Install and tighten the connection head cover. Enclosure covers must be fully engaged to meet explosion-proof requirements.

Figure 2-4. Typical Model 644H Transmitter Mounting Configuration Using Integral Mount Sensor and Assembly



644-0000B04A


## Head Mount Transmitter with Threaded Sensor

Refer to Volume 1 of the Rosemount Sensors Product Data Sheet (document number 00813-0100-2654) for complete sensor and mounting accessory information.

To complete the assembly, follow the steps as described below.

- ⚠ 1. Attach the thermowell to the pipe or process container wall. Install and tighten thermowells before applying pressure.
2. Attach necessary extension nipples and adapters. Seal the nipple and adapter threads with silicone tape.
3. Screw the sensor into the thermowell. Install drain seals if required for severe environments or to satisfy code requirements.
4. Set the transmitter failure mode switch (see Figure 2-11 on page 2-11).
5. Pull the sensor wiring leads through the extensions and adapters into the universal head. Mount the transmitter into the universal head by threading the transmitter mounting screws into the universal head mounting holes.
6. Mount the assembly into the thermowell. Seal adapter threads with silicone tape.
7. Install conduit for field wiring to the conduit entry of the universal head. Attach the sensor and power leads to the transmitter. Avoid contact with leads and terminals.
- ⚠ 8. Pull the field wiring leads through the conduit into the universal head. Attach the sensor and power leads to the transmitter. Avoid the contact with leads and terminals.
- ⚠ 9. Install and tighten the universal head cover. Enclosure covers must be fully engaged to meet explosion-proof requirements.

Figure 2-5. Typical Model644H Transmitter Mounting Configuration Using Threaded Style Sensor and Assembly



644-000A04A




### Rail Mount Transmitter with Integral Mount Sensor

Refer to Volume 2 of the Rosemount Sensors Product Data Sheet (document number 00813-0101-2654) for complete sensor and mounting accessory information.

To complete the assembly, follow the procedure described below.

1. Attach the transmitter to a suitable rail or panel.
- ⚠ 2. Attach the thermowell to the pipe or process container wall. Install and tighten the thermowell before applying pressure.
3. Attach the sensor to the connection head and mount the entire assembly to the thermowell.
4. Attach sufficient lengths of sensor lead wire to the sensor terminal block.
- ⚠ 5. Attach and tighten the connection head cover. Enclosure covers must be fully engaged to meet explosion-proof requirements.
6. Run sensor lead wires from the sensor assembly to the transmitter.
7. Set the transmitter failure mode switch (see Figure 2-11 on page 2-11).
- ⚠ 8. Attach the sensor and power leads to the transmitter. Avoid contact with leads and terminals.

Figure 2-6. Typical Rail Mount Transmitter Mounting Configuration Using Integral Mount Sensor and Assembly



644-0000C04A


### Rail Mount Transmitter with Threaded Sensor

Refer to Volume 1 of the Rosemount Sensors Product Data Sheet (document number 00813-0100-2654) for complete sensor and mounting accessory information.

To complete the assembly, follow the procedure described below.

1. Attach the transmitter to a suitable rail or panel.
- ⚠ 2. Attach the thermowell to the pipe or process container wall. Install and tighten the thermowell before applying pressure.
3. Attach necessary extension nipples and adapters. Seal the nipple and adapter threads with silicone tape.
4. Screw the sensor into the thermowell. Install drain seals if required for severe environments or to satisfy code requirements.
5. Screw the connection head to the sensor.
6. Attach the sensor lead wires to the connection head terminals.
7. Attach additional sensor lead wires from the connection head to the transmitter.
- ⚠ 8. Attach and tighten the connection head cover. Enclosure covers must be fully engaged to meet explosion-proof requirements.
9. Set the transmitter failure mode switch (see Figure 2-11 on page 2-11).
- ⚠ 10. Attach the sensor and power leads to the transmitter. Avoid contact with leads and terminals.

Figure 2-7. Typical Rail Mount Transmitter Mounting Configuration Using Threaded Style Sensor and Assembly




644-0000A04B

## Multichannel Installations

You can connect several transmitters to a single master power supply, as shown in Figure 2-8. In this case, the system may be grounded only at the negative power supply terminal. In multichannel installations where several transmitters depend on one power supply, and the loss of all transmitters would cause operational problems, consider an uninterrupted power supply or a back-up battery. The diodes shown prevent unwanted charging or discharging of the back-up battery.

Figure 2-8. Multichannel Installations



\*Between 250  $\Omega$  and 1100  $\Omega$  if no load resistor.


3044-0131A

## LCD Meter Installation

The LCD Meter for the 644H transmitter provides local indication of the transmitter output and abbreviated diagnostic messages governing transmitter operation. Transmitters ordered with the LCD meter are shipped with the meter installed. After-market installation of the meter can be performed on Model 644H transmitters that have a meter connector (transmitter Revision 5.5.2 or later). After-market installation requires the meter kit (part number 00644-4430-0001), which includes:

- LCD meter assembly (includes LCD meter, meter spacer, and 2 screws)
- Meter cover with O-ring in place

Figure 2-9. Installing the LCD Meter



---

Use the following procedure to install the meter.

1. If the transmitter is installed in a loop, secure the loop and disconnect the power. If the transmitter is installed in an enclosure, remove the cover from the enclosure.
2. Decide meter orientation (the meter can be rotated in 90° increments). To change meter orientation, remove the screws located above and below the display screen. Lift the meter off the meter spacer. Remove the 8-pin plug and re-insert it in the location that will result in the desired viewing orientation.
3. Reattach the meter to the meter spacer using the screws. If the meter was rotated 90° from its original position it will be necessary to remove the screws from their original holes and re-insert them in the adjacent screws holes.
4. Line up the 10-pin connector with the 10-pin socket and push the meter into the transmitter until it snaps into place.
5. Attach the meter cover; tighten at least one-third turn after the O-ring contacts the transmitter housing. The cover must be fully engaged to meet explosion-proof requirements.
6. Use a Model 275 HART Communicator to configure the meter to the desired display. Refer to “LCD Meter Installation” on page 2-9 for information on configuring the LCD meter.

---

**NOTE**

Observe the following LCD meter temperature limits:

Operating: -4 to 185 °F (-20 to 85 °C)

Storage: -50 to 185 °F (-45 to 85 °C)

---

**FIELD WIRING**

- ⚠ All power to the transmitter is supplied over the signal wiring. Use ordinary copper wire of sufficient size to ensure that the voltage across the transmitter power terminals does not drop below 12.0 V dc.
- ⚠ If the sensor is installed in a high-voltage environment and a fault condition or installation error occurs, the sensor leads and transmitter terminals could carry lethal voltages. Use extreme caution when making contact with the leads and terminals.

---

**NOTE**

Do not apply high voltage (e.g., ac line voltage) to the transmitter terminals. Abnormally high voltage can damage the unit. (Sensor and transmitter power terminals are rated to 42.4 V dc.)

---

For multichannel installations, see “Multichannel Installations” on page 2-9.

The transmitters will accept inputs from a variety of RTD and thermocouple types. Refer to Figure 2-11 on page 2-11 when making sensor connections.

Use the following steps to wire the transmitter:

- 1. Connect the positive lead from the power supply to the transmitter terminal marked “+” and the negative lead to the transmitter terminal marked “-” (see Figure 2-10 and Figure 2-12).
- 2. Tighten the terminal compression screws to ensure adequate contact. No additional power wiring is required.
- 3. After making connections, recheck the polarity and correctness of connections, then turn the power on.

Figure 2-10. Connecting a Communicator to a Transmitter Loop





Figure 2-11. Transmitter Power, Communication, and Sensor Terminals



## SENSOR CONNECTIONS


### RTD or Ohm Inputs

The transmitters will accept a variety of RTD configurations, including 2-wire, 3-wire, 4-wire, and compensation loop designs. If the transmitter is mounted remotely from a 3-wire or 4-wire RTD, it will operate within specifications, without recalibration, for lead wire resistances of up to 10 ohms per lead (equivalent to 1,000 feet of 20 AWG wire). In this case, the leads between the RTD and transmitter should be shielded. If using only two leads, both RTD leads are in series with the sensor element, so significant errors can occur if the lead lengths exceed three feet of 20 AWG wire (approximately 0.05 °C/ft).

### Thermocouple or Millivolt Inputs

The thermocouple can be connected directly to the transmitter for process mounting applications. Use appropriate thermocouple extension wire if mounting the transmitter remotely from the sensor. Make connections for millivolt inputs with copper wire. Use shielding for long runs of wire.

Figure 2-12. Sensor Wiring Diagrams



\* Rosemount Inc. provides 4-wire sensors for all single element RTDs. You can use these RTDs in 3-wire configurations by leaving the unneeded leads disconnected and insulated with electrical tape.

\*\* The transmitters must be configured for a 3-wire RTD in order to recognize an RTD with a compensation loop.

---

## FAILURE MODE

### Changing Switch Positions

See Figure 2-11

On the Model 644H, the failure mode switch is located on top of the transmitter near the power terminals. On the Model 644R the switch is located in the center of the front panel. Manually set the orange switch to either high or low alarm by positioning it accordingly. To set high alarm, position the switch towards the “HI” mark; to set low alarm, position the switch in the opposite direction.



Rosemount Inc

---



Safety Messages .....	page 3-1
Power Supply .....	page 3-1
Configuration .....	page 3-2

## SAFETY MESSAGES

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol ( $\triangle$ ). Please refer to the appropriate safety messages listed in “Warnings” on page 1-1 before performing an operation preceded by this symbol.

### $\triangle$ POWER SUPPLY


The dc power supply should provide power with less than 2 percent ripple. The power supplied to the transmitter should not drop below the transmitter operating voltage. Use Figure 3-1 to calculate the maximum resistance load. Compare this with the total resistance load, which is the sum of the resistance of the signal leads and the load resistance of any controller, indicator, or related pieces of equipment in the loop. The resistance of intrinsic safety barriers, if used, must be included in the maximum resistance load calculation. The supply voltage will need to be increased if the total resistance exceeds the maximum resistance load.

#### NOTE

HART communication requires a minimum of 17.75 dc power supply and a loop resistance of 250 to 1100 ohms. Do not communicate with the transmitter when power is below 12.0 V dc at transmitter terminals.

Figure 3-1. Load Limits

$$\text{Maximum Resistance Load} = 43.5 \times (\text{Supply Voltage} - 12.0)$$



644\_08A

## Surges and Transients

To protect against high-energy transients, install the transmitter into a suitable connection head with the Rosemount Model 470 Transient Protector. Refer to the Model 470 Transient Protector Product Data Sheet (document number 00813-0100-4191) for more information.

## CONFIGURATION

### Online Menu

The HART Communicator Online Menu provides direct access to Fast Key Sequences and all software functions of the transmitter. It appears automatically if the communicator is connected to an active loop with an operating transmitter or it can be selected from the Main Menu.

### Hart Fast Key Feature

HART Fast Keys are operational only from the Online Menu. To use them, you must return to the Online Menu by pressing HOME (F3) when it is available. If you do not start at the Online Menu, the HART Fast Key Sequences will not function properly.

HART Fast Key Description	Example: Changing the Date
Hart Fast Key sequences are made up of a series of numbers that correspond to the individual options in each step of the menu structure. They can be identified using the following conventions: 1 through 9 - Refer to the keys on the alpha-numeric keypad located below the dedicated keypad.	<ol style="list-style-type: none"><li>1. Following the menu structure, press 1 to reach Device Setup.</li><li>2. Press 3 for Configuration.</li><li>3. Press 4 for Device information.</li><li>4. Press 2 for Date.</li></ol> The Corresponding HART Fast Key sequence is 1, 3, 4, 2.

Figure 3-2. HART Communicator Menu Tree




Table 3-1. Model 644 Fast Key Sequence

Functions	HART Communicator Fast Keys	Functions	HART Communicator Fast Keys
Active Calibrator	1, 2, 2, 1, 3	Num Req Preams	1, 3, 3, 3, 2
Alarm/Saturation	1, 3, 3, 2	Percent Range	1, 1, 5
AO Alarm Type	1, 3, 3, 2, 1	Poll Address	1, 3, 3, 3, 1
Burst Mode	1, 3, 3, 3, 3	Process Temperature	1, 1
Burst Option	1, 3, 3, 3, 4	Process Variables	1, 1
Calibration	1, 2, 2	PV Damping	1, 3, 3, 1, 4
Callendar-Van Dusen	1, 3, 2, 1, 3	PV Unit	1, 3, 3, 1, 3
Configuration	1, 3	Range Values	1, 3, 3, 1
D/A Trim	1, 2, 2, 2	Review	1, 4
Damping Values	1, 1, 10	Scaled D/A Trim	1, 2, 2, 3
Date	1, 3, 4, 2	Sensor Connection	1, 3, 2, 1, 1
Descriptor	1, 3, 4, 3	Sensor 1 Setup	1, 3, 2, 1, 2
Device Info	1, 3, 4	Sensor Serial Number	1, 3, 2, 1, 4
Device Output Configuration	1, 3, 3	Sensor 1 Trim	1, 2, 2, 1
Diagnostics and Service	1, 2	Sensor 1 Trim-Factory	1, 2, 2, 1, 2
Filter 50/60 Hz	1, 3, 5, 1	Sensor Type	1, 3, 2, 1, 1
Hardware Rev	1, 4, 1	Software Revision	1, 4, 1
Hart Output	1, 3, 3, 3	Status	1, 2, 1, 4
Intermittent Detect	1, 3, 5, 2	Tag	1, 3, 4, 1
LCD Meter Options	1, 3, 3, 4	Terminal Temperature	1, 3, 1, 2,
Loop Test	1, 2, 1, 1	Test Device	1, 2, 1
LRV (Lower Range Value)	1, 1, 6	URV (Upper Range Value)	1, 1, 7
LSL (Lower Sensor Limit)	1, 1, 8	USL (Upper Sensor Limit)	1, 1, 9
Measurement Filtering	1, 3, 5	Variable Mapping	1, 3, 1
Message	1, 3, 4, 4	Variable Re-Map	1, 3, 1, 5
Meter Configuring	1, 3, 3, 4, 1	Write Protect	1, 2, 3
Meter Decimal Point	1, 3, 3, 4, 2	2-Wire Offset	1, 3, 2, 1, 2, 1

**4****Hardware and Software Maintenance  
and Troubleshooting**

---

Safety Message .....	page 4-1
Diagnostic Messages .....	page 4-1

---

**SAFETY MESSAGE**

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Please refer to the appropriate safety messages listed in “Warnings” on page 1-1 before performing an operation preceded by this symbol.

**DIAGNOSTIC MESSAGES****Hardware**

- ⚠ If you suspect a malfunction despite the absence of diagnostics messages on the HART Communicator display, follow the procedures described in Table 4-2 to verify that transmitter hardware and process connections are in good working order. Under each of four major symptoms, specific suggestions are offered for solving the problem.

TABLE 4-2. Hardware diagnostic messages

Symptom	Potential Source	Corrective Action
Transmitter Does Not Communicate with HART Communicator	Loop Wiring	<ul style="list-style-type: none"> <li>Check the revision level of the transmitter device descriptors (DDs). The communicator should report Dev v5, DD v2.</li> <li>Check for a minimum of 250 ohms resistance between the power supply and HART-based communicator connection.</li> <li>Check for adequate voltage to the transmitter. If a HART-based communicator is connected and 250 ohms resistance is in the loop, the transmitter requires a minimum of 12.0 V at the terminals to operate (over entire 3.75 to 23 mA operating range).</li> <li>Check for intermittent shorts, open circuits, and multiple grounds.</li> <li>Specify the transmitter by tag number. For certain non-standard transmitter installations, specify the transmitter tag number to initiate communications.</li> </ul>
High Output	Sensor Input Failure or Connection	<ul style="list-style-type: none"> <li>Connect a HART-based communicator and enter the Transmitter test mode to isolate a sensor failure.</li> <li>Check for a sensor open or short circuit.</li> <li>Check the process variable to see if it is out of range.</li> </ul>
	Loop Wiring	<ul style="list-style-type: none"> <li>Check for dirty or defective terminals, interconnecting pins, or receptacles.</li> </ul>
	Power Supply	<ul style="list-style-type: none"> <li>Check the output voltage of the power supply at the transmitter terminals. It should be 12.0 to 42.4 V dc (over entire 3.75 to 23 mA operating range).</li> </ul>
Erratic Output	Electronics Module	<ul style="list-style-type: none"> <li>Connect a HART-based communicator and enter the transmitter status mode to isolate module failure.</li> <li>Connect a HART-based communicator and check the sensor limits to ensure calibration adjustments are within the sensor range.</li> </ul>
	Loop Wiring	<ul style="list-style-type: none"> <li>Check for adequate voltage to the transmitter. It should be 12.0 to 42.4 V dc at the transmitter terminals (over entire 3.75 to 23 mA operating range).</li> <li>Check for intermittent shorts, open circuits, and multiple grounds.</li> <li>Connect a HART-based communicator and enter the Loop test mode to generate signals of 4 mA, 20 mA, and user-selected values.</li> </ul>
	Electronics Module	<ul style="list-style-type: none"> <li>Connect a HART-based communicator and enter the Transmitter test mode to isolate module failure.</li> </ul>

Symptom	Potential Source	Corrective Action
Low Output or No Output	Sensor Element	<ul style="list-style-type: none"><li>• Connect a HART-based communicator and enter the Transmitter test mode to isolate a sensor failure.</li><li>• Check the process variable to see if it is out of range.</li></ul>
	Loop Wiring	<ul style="list-style-type: none"><li>• Check for adequate voltage to the transmitter. It should be 12.0 to 42.4 V dc (over entire 3.75 to 23 mA operating range).</li><li>• Check for shorts and multiple grounds.</li><li>• Check for proper polarity at the signal terminal.</li><li>• Check the loop impedance.</li><li>• Connect a HART-based communicator and enter the Loop test mode.</li><li>• Check wire insulation to detect possible shorts to ground.</li></ul>
	Electronics Module	<ul style="list-style-type: none"><li>• Connect a HART-based communicator and check the sensor limits to ensure calibration adjustments are within the sensor range.</li><li>• Connect a HART-based communicator and enter the Transmitter test mode to isolate an electronics module failure.</li></ul>

## Model 275 HART Communicator

Table 4-3 provides a guide to diagnostic messages used by the Model 275 HART Communicator (HC).

Variable parameters within the text of a message are indicated with the notation *<variable parameter>*.

Reference to the name of another message is identified by the notation *[another message]*.

TABLE 4-3. Model 275 HART Diagnostics Messages

Message	Description
Add item for ALL device types or only for this ONE device type	Asks the user whether the hot key item being added should be added for all device types or only for the type of device that is connected.
Command Not Implemented	The connected device does not support this function.
Communication Error	Either a device sends back a response indicating that the message it received was unintelligible, or the HC cannot understand the response from the device.
Configuration memory not compatible with connected device	The configuration stored in memory is incompatible with the device to which a transfer has been requested.
Device Busy	The connected device is busy performing another task.
Device Disconnected	Device fails to respond to a command.
Device write protected	Device is in write-protect mode. Data can not be written.
Device write protected. Do you still want to shut off?	Device is in write-protect mode. Press YES to turn the HC off and lose the unsent data.
Display value of variable on hotkey menu?	Asks whether the value of the variable should be displayed adjacent to its label on the hotkey menu if the item being added to the hotkey menu is a variable.
Download data from configuration memory to device	Prompts user to press SEND softkey to initiate a memory to device transfer.
Exceed field width	Indicates that the field width for the current arithmetic variable exceeds the device- specified description edit format.
Exceed precision	Indicates that the precision for the current arithmetic variable exceeds the device- specified description edit format.
Ignore next 50 occurrences of status?	Asked after displaying device status. Softkey answer determines whether next 50 occurrences of device status will be ignored or displayed.
Illegal character	An invalid character for the variable type was entered.



Message	Description
Illegal date	The day portion of the date is invalid.
Illegal month	The month portion of the date is invalid.
Illegal year	The year portion of the date is invalid.
Incomplete exponent	The exponent of a scientific notation floating point variable is incomplete.
Incomplete field	The value entered is not complete for the variable type.
Looking for a device	Polling for multidropped devices at addresses 1–15.
Mark as read only variable on hotkey menu?	Asks whether the user should be allowed to edit the variable from the hotkey menu if the item being added to the hotkey menu is a variable.
No device configuration in configuration memory	There is no configuration saved in memory available to re-configure off-line or transfer to a device.
No Device Found	Poll of address zero fails to find a device, or poll of all addresses fails to find a device if auto-poll is enabled.
No hotkey menu available for this device.	There is no menu named "hotkey" defined in the device description for this device.
No offline devices available.	There are no device descriptions available to be used to configure a device offline.
No simulation devices available.	There are no device descriptions available to simulate a device.
No UPLOAD_VARIABLES in ddl for this device	There is no menu named "upload_variables" defined in the device description for this device. This menu is required for offline configuration.
No Valid Items	The selected menu or edit display contains no valid items.
OFF KEY DISABLED	Appears when the user attempts to turn the HC off before sending modified data or before completing a method.
Online device disconnected with unsent data. RETRY or OK to lose data.	There is unsent data for a previously connected device. Press RETRY to send data, or press OK to disconnect and lose unsent data.
Out of memory for hotkey configuration. Delete unnecessary items.	There is no more memory available to store additional hotkey items. Unnecessary items should be deleted to make space available.
Overwrite existing configuration memory	Requests permission to overwrite existing configuration either by a device-to-memory transfer or by an offline configuration. User answers using the softkeys.
Press OK.	Press the OK softkey. This message usually appears after an error message from the application or as a result of HART communications.
Restore device value?	The edited value that was sent to a device was not properly implemented. Restoring the device value returns the variable to its original value.

Message	Description
Save data from device to configuration memory	Prompts user to press SAVE softkey to initiate a device-to-memory transfer.
Saving data to configuration memory.	Data is being transferred from a device to configuration memory.
Sending data to device.	Data is being transferred from configuration memory to a device.
There are write only variables which have not been edited. Please edit them.	There are write-only variables which have not been set by the user. These variables should be set or invalid values may be sent to the device.
There is unsent data. Send it before shutting off?	Press YES to send unsent data and turn the HC off. Press NO to turn the HC off and lose the unsent data.
Too few data bytes received	Command returns fewer data bytes than expected as determined by the device description.
Transmitter Fault	Device returns a command response indicating a fault with the connected device.
Units for <variable label> has changed. Unit must be sent before editing, or invalid data will be sent.	The engineering units for this variable have been edited. Send engineering units to the device before editing this variable.
Unsent data to online device. SEND or LOSE data	There is unsent data for a previously connected device which must be sent or thrown away before connecting to another device.
Use up/down arrows to change contrast. Press DONE when done.	Gives direction to change the contrast of the HC display.
Value out of range	The user-entered value is either not within the range for the given type and size of variable or not within the min/max specified by the device.
<message> occurred reading/writing <variable label>	Either a read/write command indicates too few data bytes received, transmitter fault, invalid response code, invalid response command, invalid reply data field, or failed pre- or post-read method; or a response code of any class other than SUCCESS is returned reading a particular variable.
<variable label> has an unknown value. Unit must be sent before editing, or invalid data will be sent.	A variable related to this variable has been edited. Send related variable to the device before editing this variable.

## LCD Meter

In addition to the output, the LCD meter displays abbreviated diagnostic messages for troubleshooting the transmitter. To determine the cause of a message, use a Model 275 HART Communicator to further interrogate the transmitter. A description of each diagnostic message is identified in Table 4-4. The device sometimes requires additional interrogation to determine the source of the warning. Contact Rosemount Customer Central at (800) 999-9307 or your local Rosemount support center for further information.

TABLE 4-4. LCD Meter Diagnostics

Alarm	Description
DEV FAIL	<p>The top line of the display scrolls through the following three messages:</p> <ul style="list-style-type: none"> <li>• “BAD”</li> <li>• “DEV”</li> <li>• “FAIL”</li> </ul> <p>This message indicates one of several conditions. For example, the transmitter may have experienced an electronics failure while attempting to store information. If diagnostics indicate an electronics failure, replace the transmitter with a new one. Contact the nearest Rosemount Field service Center if necessary.</p>
SNSR FAIL	<p>The top line of the display scrolls through the following three messages:</p> <ul style="list-style-type: none"> <li>• “BAD”</li> <li>• “SNSR”</li> <li>• “FAIL”</li> </ul> <p>The bottom line display s the name of the sensor that has failed. This message indicates that the transmitter has detected an open or shorted sensor condition. The sensor may be disconnected, connected improperly, or malfunctioning. Check the sensor connections and sensor continuity.</p>
UNCRN	<p>The top line of the display alternates between “UNCRN” and the sensor value. The bottom line will display the name of the sensor for which this message applies. The uncertain message is displayed when the sensor reading is outside of the acceptable temperature range for the particular sensor type.</p>
FIXED	<p>During a loop test or a 4–20 mA output trim, the analog output defaults to a fixed value. The top line of the display alternates between “FIXED” and the amount of current selected in milliamperes. The bottom line will hold on “AO mA.”</p>

---

Alarm	Description
OFLOW	The location of the decimal point, as configured in the meter setup, is not compatible with the value to be displayed by the meter. For example, if the meter is measuring a process temperature greater than 9.9999 degrees and the meter decimal point is set to 4-digit precision, the meter will display an "OFLOW" message because it is only capable of displaying a maximum of 9.9999 when set to 4-digit precision.
ALARM	When a failure occurs and the meter is configured to display Primary Variable Percent of Range and/or Analog Output, the top line of the meter will display "ALARM." This indicates that the transmitter is in failure mode.
SAT	When the transmitter output saturates and the meter is configured to display Primary Variable Percent of Range and/or Analog Output, the top line of the meter will display "SAT." This indicates that the transmitter output has reached saturation level.

Specifications .....	page A-1
Dimensional Drawings .....	page A-8
Ordering Information .....	page A-11
Configuration .....	page A-13

## SPECIFICATIONS

### Functional

#### Inputs

User-selectable; sensor terminals rated to 42.4 V dc.

#### Output

2-wire 4–20 mA, linear with temperature or input; digital output signal superimposed on 4–20 mA signal, available for a HART communicator or control system interface

#### Isolation

Input/output isolation tested to 500 V ac rms (707 V dc) at 50/60 Hz

#### Local Display

The optional five-digit integral LCD meter includes a floating or fixed decimal point. It also displays options for engineering units (°F, °C, °R, K, Ω, and millivolts), milliamperes, and percent of span. The display can be configured to alternate between selected display options. Display settings are preconfigured at the factory according to the standard transmitter configuration. They can be reconfigured in the field using a HART Communicator.

#### Humidity Limits

0–99% relative humidity, non-condensing

#### Turn-on Time

Performance within specifications is less than 5.0 seconds after power is applied to transmitter when damping value is set to zero seconds

#### Update Time

Approximately 0.5 seconds

#### Power Supply

An external power supply is required. The transmitter operates on 12.0 to 42.4 V dc transmitter terminal voltage with load resistance between 250 and 1100 ohms. A minimum of 17.75 V dc power supply is required with a load of 250 ohms. Transmitter power terminals are rated to 42.4 V dc.

**NOTE**

A HART Communicator requires a loop resistance between 250 and 1100 ohms. Do not communicate with the transmitter when power is below 12 V dc at the transmitter terminals.

**Temperature Limits**

	Operating Limit		Storage Limit	
	°F	°C	°F	°C
With LCD Meter	–4 to 185	–20 to 85	–50 to 185	–45 to 85
Without LCD Meter	–40 to 185	–40 to 85	–58 to 248	–50 to 120

**Failure Mode**

The values at which the transmitter drives its output in failure mode depends on whether it is configured to standard, NAMUR-compliant (NAMUR recommendation NE 43, June 1997), or custom operation. The values for standard and NAMUR-compliant operation are as follows:

Table A-5. Standard and NAMUR-Compliant Operation Parameters

	Standard	NAMUR-Compliant
Linear Output:	$3.9 \leq I \leq 20.5 \text{ mA}$	$3.8 \leq I \leq 20.5 \text{ mA}$
Fail high:	$21.0 \leq I \leq 23.0 \text{ mA}$ (Default)	$21.0 \leq I \leq 23.0 \text{ mA}$
Fail low:	$I \leq 3.75 \text{ mA}$	$I \leq 3.6 \text{ mA}$

**Custom Alarm and Saturation Levels**

Custom factory configuration of alarm and saturation level is available with option code C1. These values can also be configured in the field using a HART Communicator.

## Performance

The Model 644 transmitters maintain a specification conformance of at least  $3\sigma$ .

### Accuracy

Table A-6. Model 644 Input Options and Accuracy.

Sensor Options	Sensor Reference	Input Ranges		Recommended Min. Span <sup>(1)</sup>		Digital Accuracy <sup>(2)</sup>		D/A Accuracy <sup>(3)</sup>
2-, 3-, 4-Wire RTDs		°C	°F	°C	°F	°C	°F	
Pt 100	IEC 751, 1995 ( $\alpha = 0.00385$ )	–200 to 850	–328 to 1562	10	18	$\pm 0.15$	$\pm 0.27$	$\pm 0.03\%$ of span
PT 100	JIS 1604, 1981 ( $\alpha = 0.003916$ )	–200 to 645	–328 to 1193	10	18	$\pm 0.15$	$\pm 0.27$	$\pm 0.03\%$ of span
Pt 200	IEC 751, 1995 ( $\alpha = 0.00385$ )	–200 to 850	–328 to 1562	10	18	$\pm 0.27$	$\pm 0.49$	$\pm 0.03\%$ of span
Pt 500	IEC 751, 1995 ( $\alpha = 0.00385$ )	–200 to 850	–328 to 1562	10	18	$\pm 0.19$	$\pm 0.34$	$\pm 0.03\%$ of span
Pt 1000	IEC 751, 1995 ( $\alpha = 0.00385$ )	–200 to 300	–328 to 572	10	18	$\pm 0.19$	$\pm 0.34$	$\pm 0.03\%$ of span
Ni 120	Edison Curve No. 7	–70 to 300	–94 to 572	10	18	$\pm 0.15$	$\pm 0.27$	$\pm 0.03\%$ of span
Cu 10	Edison Copper Winding No. 15	–50 to 250	–58 to 482	10	18	$\pm 1.40$	$\pm 2.52$	$\pm 0.03\%$ of span
Thermocouples <sup>(4)</sup>								
Type B <sup>(5)</sup>	NIST Monograph 175, IEC 584	100 to 1820	212 to 3308	25	45	$\pm 0.77$	$\pm 1.39$	$\pm 0.03\%$ of span
Type E	NIST Monograph 175, IEC 584	–50 to 1000	–58 to 1832	25	45	$\pm 0.20$	$\pm 0.36$	$\pm 0.03\%$ of span
Type J	NIST Monograph 175, IEC 584	–180 to 760	–292 to 1400	25	45	$\pm 0.35$	$\pm 0.63$	$\pm 0.03\%$ of span
Type K <sup>(6)</sup>	NIST Monograph 175, IEC 584	–180 to 1372	–292 to 2502	25	45	$\pm 0.50$	$\pm 0.90$	$\pm 0.03\%$ of span
Type N	NIST Monograph 175, IEC 584	–200 to 1300	–328 to 2372	25	45	$\pm 0.50$	$\pm 0.90$	$\pm 0.03\%$ of span
Type R	NIST Monograph 175, IEC 584	0 to 1768	32 to 3214	25	45	$\pm 0.75$	$\pm 1.35$	$\pm 0.03\%$ of span
Type S	NIST Monograph 175, IEC 584	0 to 1768	32 to 3214	25	45	$\pm 0.70$	$\pm 1.26$	$\pm 0.03\%$ of span
Type T	NIST Monograph 175, IEC 584	–200 to 400	–328 to 752	25	45	$\pm 0.35$	$\pm 0.63$	$\pm 0.03\%$ of span
DIN Type L	DIN 43710	–200 to 900	–328 to 1652	25	45	$\pm 0.35$	$\pm 0.63$	$\pm 0.03\%$ of span

Sensor Options	Sensor Reference	Input Ranges		Recommended Min. Span <sup>(1)</sup>		Digital Accuracy <sup>(2)</sup>		D/A Accuracy <sup>(3)</sup>
DIN Type U	DIN 43710	–200 to 600	–328 to 1112	25	45	± 0.35	± 0.63	±0.03% of span
Type W5Re/W26Re	ASTM E 988–96	0 to 2000	32 to 3632	25	45	± 0.70	± 1.26	±0.03% of span
Millivolt Input		–10 to 100 mV		3 mV		±0.015 mV		±0.03% of span
2-, 3-, 4-Wire Ohm Input		0 to 2000 ohms		20 ohm		±0.45 ohm		±0.03% of span

(1) No minimum or maximum span restrictions within the input ranges. Recommended minimum span will hold noise within accuracy specification with damping at zero seconds.

(2) Digital accuracy: Digital output can be accessed by HART Communicator or Rosemount control system.

(3) Total Analog accuracy is the sum of digital and D/A accuracies.

(4) Total digital accuracy for thermocouple measurement: sum of digital accuracy +0.5 °C

(5) Digital accuracy for NIST Type B T/C is ±3.0 °C from 100 to 300 °C.

(6) Digital accuracy for NIST Type K T/C is ±0.70 °C from –292 to –130 °F (–180 to –90 °C).

#### Accuracy Example

When using a Pt 100 ( $\alpha = 0.00385$ ) sensor input with a 0 to 100 °C span: Digital accuracy would be ±0.15 °C, D/A accuracy would be ±0.03% of 100 °C or ±0.03 °C, Total = ±0.18 °C.



**Ambient Temperature Effect**

Transmitters can be installed in locations where the ambient temperature is between  $-40$  and  $85$  °C ( $-40$  and  $185$  °F).

Sensor Options	Temperature Effects per 1.0 °C (1.8 °F) Change in Ambient Temperature <sup>(1)</sup>	Ranges	D/A Effect
2-, 3-, 4-Wire RTDs			
Pt 100 ( $\alpha = 0.00385$ )	• 0.003 °C (0.0054 °F)	Entire sensor input range	0.001% of span
PT 100 ( $\alpha = 0.003916$ )	• 0.003 °C (0.0054 °F)	Entire sensor input range	0.001% of span
Pt 200	• 0.004 °C (0.0072 °F)	Entire sensor input range	0.001% of span
Pt 500	• 0.003 °C (0.0054 °F)	Entire sensor input range	0.001% of span
Pt 1000	• 0.003 °C (0.0054 °F)	Entire sensor input range	0.001% of span
Ni 120	• 0.003 °C (0.0054 °F)	Entire sensor input range	0.001% of span
Cu 10	• 0.03 °C (0.054 °F)	Entire sensor input range	0.001% of span
Thermocouples			
Type B	<ul style="list-style-type: none"> <li>• 0.014 °C</li> <li>• 0.032 °C – (0.0025% of (R – 300))</li> <li>• 0.054 °C – (0.011% of (R – 100))</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 1000^{\circ}\text{C}</math></li> <li>• <math>300^{\circ}\text{C} \leq R &lt; 1000^{\circ}\text{C}</math></li> <li>• <math>100^{\circ}\text{C} \leq R &lt; 300^{\circ}\text{C}</math></li> </ul>	0.001% of span
Type E	• 0.005 °C + (0.00043% of R)	• All	0.001% of span
Type J	<ul style="list-style-type: none"> <li>• 0.0054 °C + (0.0029% of R)</li> <li>• 0.0054 °C + (0.0025% of absolute value R)</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 0^{\circ}\text{C}</math></li> <li>• <math>R &lt; 0^{\circ}\text{C}</math></li> </ul>	0.001% of span
Type K	<ul style="list-style-type: none"> <li>• 0.0061 °C + (0.00054% of R)</li> <li>• 0.0061 °C + (0.0025% of absolute value R)</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 0^{\circ}\text{C}</math></li> <li>• <math>R &lt; 0^{\circ}\text{C}</math></li> </ul>	0.001% of span
Type N	• 0.0068 °C + (0.00036% of R)	• All	0.001% of span
Type R, S, W5Re/ W26Re	<ul style="list-style-type: none"> <li>• 0.016 °C</li> <li>• 0.023 °C – (0.0036% of R)</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 200^{\circ}\text{C}</math></li> <li>• <math>R &lt; 200^{\circ}\text{C}</math></li> </ul>	0.001% of span
Type T	<ul style="list-style-type: none"> <li>• 0.0064 °C</li> <li>• 0.0064 °C + (0.0043% of absolute value R)</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 0^{\circ}\text{C}</math></li> <li>• <math>R &lt; 0^{\circ}\text{C}</math></li> </ul>	0.001% of span
DIN Type L	<ul style="list-style-type: none"> <li>• 0.0054 °C + (0.00029% of R)</li> <li>• 0.0054 °C + (0.0025% of absolute value R)</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 0^{\circ}\text{C}</math></li> <li>• <math>R &lt; 0^{\circ}\text{C}</math></li> </ul>	0.001% of span
DIN Type U	<ul style="list-style-type: none"> <li>• 0.0064 °C</li> <li>• 0.0064 °C + (0.0043% of absolute value R)</li> </ul>	<ul style="list-style-type: none"> <li>• <math>R \geq 0^{\circ}\text{C}</math></li> <li>• <math>R &lt; 0^{\circ}\text{C}</math></li> </ul>	0.001% of span
Millivolt Input	• 0.0005 mV	Entire sensor input range	0.001% of span
2-, 3-, 4-Wire Ohm Input	0.0084 $\Omega$	Entire sensor input range	0.001% of span

(1) Change in ambient is with reference to the calibration temperature of the transmitter 68 °F (20 °C) from factory.

**Temperature Effects Example**

When using a Pt 100 ( $\alpha = 0.00385$ ) sensor input with a 0–100 °C span at 30 °C ambient temperature:

Digital Temperature Effects:	$0.003\text{ °C} \times (30 - 20) = 0.03\text{ °C}$
D/A Effect:	$[0.001\% \text{ of } 100] \times (30 - 20) = 0.01\text{ °C}$
Worst Case Error:	Digital + D/A + Digital Temperature Effects + D/A Effects = 0.15 °C + 0.03 °C + 0.03 °C + 0.01 °C = 0.22 °C
Total Probable Error:	$\sqrt{0.15^2 + 0.03^2 + 0.03^2 + 0.01^2} = 0.16\text{ °C}$

RTDs and thermocouples have a stability of  $\pm 0.1\%$  of reading or 0.1 °C (whichever is greater) for twelve months.

**Power Supply Effect**

Less than  $\pm 0.005\%$  of span per volt

**Vibration Effect**

The Model 644H and Model 644R are tested to the following specifications with no effect on performance:

Frequency	Vibration
10–60 Hz	0.21 mm peak displacement
60–500 Hz	3 g peak acceleration

**CE Electromagnetic Compatibility Compliance Testing**

The Models 644H and 644R meet all requirements listed under IEC 61326: Amendment 1, 1998.

**Self Calibration**

The analog-to-digital measurement circuitry automatically self-calibrates for each temperature update by comparing the dynamic measurement to extremely stable and accurate internal reference elements.

**Electrical Connections****Power and Sensor Terminals**

Model 644H	Compression screws permanently fixed to terminal block	Clips permanently fixed to terminal block
Model 644R:	Compression screw permanently fixed to front panel	Clips permanently fixed to front panel

WAGO® spring clamp terminals are optional (option code G5)

**Materials of Construction****Construction Material for the Electronics Housing and Terminal Block**

Model 644H	Noryl® glass reinforced
Model 644R:	Lexan® polycarbonate

The Model 644H installs in a connection head or universal head mounted directly on a sensor assembly, apart from a sensor assembly using a universal head, or to a DIN rail using an optional mounting clip. The Model 644R mounts directly to a wall or to a DIN rail.

**Weight**

Code	Options	Add <sup>(1)</sup>
Model 644H	Head Mount	78 (2.75)
M5	LCD Meter	34 (1.20)
J5, J6	Universal Head, Standard Cover	520 (18.43)
J5, J6	Universal Head, Meter Cover	604 (21.27)
Model 644R	Rail Mount	173 (6.10)


(1) All weights are in grams (ounces).



**Enclosure Ratings (Model 644H)**

Option codes J5 and J6 are NEMA 4X, IP66, and IP68.

Option code J6 is CSA Enclosure Type 4X

DIMENSIONAL DRAWINGS



Threaded-Sensor Universal Head (Option code J5 or J6) Shown with LCD Meter	Integral DIN Style Sensor Connection Head (see note below)
 <p>112 (4.41) 96 (3.76) 95 (3.74) 103 (4.03) with LCD Meter 75 (2.93) Label Meter Cover SST "U" Bolt Mounting, 2-inch Pipe</p>	 <p>104 (4.09) 128 (5.04) with LCD Meter 100 (3.93)</p>
<p><i>Note: A "U" Bolt is shipped with each universal head unless assembly option X1, X2, or X3 is ordered. However, since the head can be integrally mounted to the sensor, it may not need to be used.</i></p> <p><i>Note: The DIN Style Integral sensor connection head is only available through Volume 2 of the Rosemount Temperature Sensors and Accessories Product Data Sheet (document number 00810-0101-2654).</i></p>	
Dimensions are in millimeters (inches)	

Mounting		
G-Rail (asymmetric)	Top Hat Rail (symmetric)	Universal Clip for Mounting to a Wall or a Rail (part number 03044-4301-0001)
<div> <div> <div>Mounting Hardware</div> <div>Transmitter</div> <div>Rail Clip</div> </div> <div> </div> </div>	<div> <div> <div>Mounting Hardware</div> <div>Transmitter</div> <div>Rail Clip</div> </div> <div> </div> </div>	<div> <div> <div>G-Rail Grooves</div> <div>Top Hat Rail Grooves</div> <div>Screw Holes for Mounting to a Wall</div> </div> <div> </div> </div>
Model 644H Retrofit Kit		
<div> <div> </div> <div> <p>Note: Kit (part number 00644-5301-0010 includes mounting hardware and both types of rail kits.</p> </div> </div>		<div> <div> <div>Existing Threaded Sensor Connection Head (former option code L1)</div> <div>Kit includes replacement bracket and screws.</div> </div> <div> </div> </div> <div> <p>Note: Kit (part number 00644-5321-0010) includes a new mounting bracket and the hardware necessary to facilitate the installation.</p> </div>

3044-4001A01B,  
644-5302B01A, D02A

3044-0000C01B, D01B,  
644-1041B02B, G02B

## ORDERING INFORMATION

Table A-7. Model 644H and Model 644R Ordering Table

		• = Available — = Not available		
Model	Product Description	Head Mount	Rail Mount	
644H	Smart Head Mount Temperature Transmitter	•	—	
644R	Smart Rail Mount Temperature Transmitter	—		
Code	Hazardous Area Certifications	Enclosure Purchase Required?	Head Mount	Rail Mount
E5	FM Explosion-Proof Approval	Yes	•	—
I5	FM Intrinsic Safety and Non-Incendive Approval	No*	•	•
K5	FM Intrinsic Safety, Non-Incendive, and Explosion-Proof Approval Combination	Yes	•	—
I6	CSA Intrinsic Safety and Non-Incendive Approval	No*	•	•
C6	CSA Intrinsic Safety, Non-Incendive, and Explosion-Proof Approval Combination	Yes	•	—
N1	CENELEC/BASIEFA Type n Approval	Yes	•	—
ED	CENELEC/KEMA Flameproof Approval	Yes	•	—
I1	CENELEC/BASIEFA Intrinsic Safety Approval	No*	•	•
E7	SAA Flameproof Approval. <i>Consult factory for availability.</i>	Yes	•	—
N7	SAA Type N Approval. <i>Consult factory for availability</i>	Yes	•	—
I7	SAA Intrinsic Safety Approval. <i>Consult factory for availability.</i>	No*	•	•
NA	No Approval	No*	•	•
* Transmitters with intrinsic safety approvals can be ordered without enclosures. However, to meet intrinsic safety requirements, the transmitter must be installed in an enclosure with IP20 or higher rating. Model 644H transmitters ordered with enclosure options J5 or J6 meet this requirement.				
Code	Options			
Assembly Options (Model 644H Only)				
X1	Assemble Transmitter to a Sensor Assembly (hand tight, <i>Teflon</i> ® (PTFE) tape where appropriate, fully wired)	•	•	—
X2	Assemble Transmitter to a Sensor Assembly (hand tight, no <i>Teflon</i> (PTFE) tape, unwired)	•	•	—
X3	Assemble Transmitter to a Sensor Assembly (wrench tight, <i>Teflon</i> (PTFE) where appropriate, fully wired)	•	•	—
<i>Note: If ordering X1, X2, X3, specify the same code on the sensor model number. Option codes X1 and X3 are not available with CSA Approvals (Hazardous Area Certifications C6 or I6)</i>				
Enclosure Options Threaded Style Temperature Sensor Users (Americas and Asia Pacific) <i>Remote/Integral Mount</i>				
J6	Universal Head (Junction Box), Aluminum Alloy with 2-in. SST Pipe Bracket (M20 Entries)	•	•	—

Table A-7. Model 644H and Model 644R Ordering Table

		• = Available	— = Not available
	DIN Plate Style Temperature Sensor Users (EMEA-Europe, Middle East, and Africa) <i>Remote Mount</i>		
J5	Universal Head (Junction Box), Aluminum Alloy with 2-in. SST Pipe Bracket (M20 Entries)	•	—
J6	Universal Head (Junction Box), Aluminum Alloy with 2-in. SST Pipe Bracket (½–14 NPT Entries) <i>Integral Mount</i>	•	—
	*****Order connection head through Volume 2 of the Rosemount Temperature Sensor and Accessories Product Data Sheet (document number 00810-0101-2654) sensor model number*****		
	Configuration Options		
C1	Factory Custom Configuration of Alarm and Saturation Levels, Date, Descriptor, and Message Fields.	•	•
A1	Analog Output Levels Compliant with NAMUR-Recommendations NE 43: June 1997	•	•
CN	Analog Output Levels Compliant with NAMUR-Recommendations NE 43: June 1997: Alarm Configuration Low	•	•
F6	60 Hz Line Voltage Filter	•	•
	Calibration Options		
C2	Transmitter-Sensor Matching Trim to specific Rosemount RTD Calibration Schedule.	•	•
C4	5-Point Calibration. <i>Use Q4 option to generate a calibration certificate</i>	•	•
Q4	Calibration Certificate. <i>3-Point standard; use C4 with Q4 option for a 5-point calibration certificate.</i>	•	•
	Accessory Options (Model 644H only)		
M5	LCD Meter Option. <i>Enclosure Option J5 or J6 is required when ordering flame-proof or explosion-proof approvals.</i>	•	—
G1	External Ground Screw. <i>Only available with options J5 or J6.</i>	•	—
G2	Cable Gland. <i>Only available with option code J5.</i>	•	—
G3	Cover Chain. <i>Only available with enclosure options J5 or J6. Not available with LCD meter option code M5.</i>	•	—
G5	WAGO Spring Clamp Terminals	•	—
Typical Model Number – Americas and Asia Pacific: 644H E5 X1 J6 M5 F6			
Typical Model Number – Europe, Middle East, Africa: 644H ED X1 M5			



Table A-8. Transmitter Accessories

Part Description	Part Number	Availability
Aluminum Alloy Universal Head, Standard Cover—M20 Entries	00644-4420-0002	•
Aluminum Alloy Universal Head, Meter Cover—M20 Entries	00644-4420-0102	•
Aluminum Alloy Universal Head, Standard Cover—½-14 NPT Entries	00644-4420-0001	•
Aluminum Alloy Universal Head, Meter Cover—½-14 NPT Entries	00644-4420-0101	•
LCD Meter (includes meter and meter space assembly)	00644-4430-0002	•
LCD Meter Kit (includes meter and meter space assembly, and meter cover)	00644-4430-0001	•
Ground Screw Assembly Kit	00644-4431-0001	•
Kit, Hardware for Mounting a Model 644H to a DIN rail (includes clips for symmetrical and asymmetrical rails)	00644-5301-0010	•
Kit, Hardware for Retrofitting a Model 644H in an existing Threaded Sensor Connection Head (former option code L1)	00644-5321-0010	•
Blank Transmitter Configuration Labels (sheet of 48)	00644-5154-0001	•
Universal Clip for Rail or Wall Mount	03044-4103-0001	•
24 Inches of Symmetric (Top Hat) Rail	03044-4200-0001	•
24 Inches of Asymmetric (G) Rail	03044-4201-0001	•
Ground Clamp for symmetric or asymmetric rail	03044-4202-0001	•
End Clamp for symmetric or asymmetric rail	03044-4203-0001	•
Snap Rings Kit (used for assembly to a DIN sensor)	00644-4432-0001	•

## CONFIGURATION

### Standard

Unless specified, the transmitter will be shipped as follows:

Table A-9. Standard Configuration Parameters

Sensor Type:	RTD, PT 100 ( $\alpha = 0.00385$ , 4-wire)
4 mA Value:	0 °C
20 mA Value:	100 °C
Damping:	5 seconds
Output:	Linear with temperature
Failure Mode:	High/Upscale
Line Voltage Filter:	50 Hz
Tag:	See "Tagging"

## Custom

The transmitter can be ordered with custom configuration. Use Table A-10 to determine the requirements when specifying the custom configuration.

Table A-10. Custom Configuration Requirements/Specification

Option Code	Requirements/Specification
C1: Factory Configuration Data	Date: day/month/year Descriptor: 16 alphanumeric characters Message: 32 alphanumeric character Analog Output: Alarm and saturation levels
C2: Transmitter Sensor Matching	Specify a Rosemount 65, 68, or 78 RTD order with a special characterization curve
A1: NAMUR-compliant	See Table A-5, "Standard and NAMUR-Compliant Operation Parameters," on page 2
CN: NAMUR-Compliant, Low Alarm	See Table A-5, "Standard and NAMUR-Compliant Operation Parameters," on page 2
C4: Five Point Calibration	Will include five-point calibration at 0, 25, 50, 75, and 100% analog and digital output points. Use with Rosemount Calibration Certificate Q4.
F6: 60 Hz Line Filter	Calibrated to a 60 Hz line voltage filter instead of the standard 50 Hz filter

## Tagging

Hardware Tag	Software Tag
<ul style="list-style-type: none"> <li>No charge</li> <li>Tagged in accordance with customer requirements</li> <li>Tags are adhesive labels</li> <li>Permanently attached to transmitter</li> <li>Character height is 1/16 -in (1.6 mm)</li> </ul>	<ul style="list-style-type: none"> <li>No charge</li> <li>The transmitter can store up to 8 characters. If no characters are specified, the first 8 characters of the hardware tag are the default.</li> </ul>

**B****Hazardous Locations Certifications**

Safety Messages .....	page B-1
Hazardous Locations Certifications .....	page B-1
European ATEX Directive Information. ....	page B-4
Installation Drawings .....	page B-5

**SAFETY MESSAGES**

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Please refer to the following safety messages before performing an operation preceded by this symbol.

**⚠ WARNING**

Once a device labeled with multiple approval types is installed, it should not be reinstalled using any of the other labeled approval types. To ensure this, the approval label should be permanently marked to distinguish the used from the unused approval type(s).

**HAZARDOUS LOCATIONS CERTIFICATIONS**

⚠ The Models 644 are available with circuitry that is suitable for intrinsically safe operation. The Model 644H is available with optional explosion-proof enclosures and can be specified for non-incendive operation. Individual transmitters are clearly marked with a tag indicating the approvals they carry.

To maintain certified ratings for installed transmitters, they must be installed in accordance with all applicable installation codes and approval drawings. Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certification.

**IMPORTANT**

Once a device labeled with multiple approval types is installed, it should not be reinstalled using any of the other labeled approval types. To ensure this, the approval label should be permanently marked to distinguish the used from the unused approval type(s).

---

**Factory Mutual (FM) Approvals**

- E5** Explosion-Proof for Class I, Division 1, Groups B, C, and D. Dust-Ignition Proof for Class II, Division 1, Groups E, F, and G. Dust-Ignition Proof for Class III, Division 1 hazardous locations when installed in accordance with Rosemount Drawing 00644-1049. Non-Incendive for Class I, Division 2, Groups A, B, C, and D. Ambient temperature limits: -50 to 85 °C. Conduit seal not required for compliance with NEC 501-5a(1). Temperature Code T5 ( $T_{amb} = 85\text{ °C}$ )

---

**NOTE:**

Approval E5 is only available with 644H option codes J5 and J6.

---

- I5** Intrinsically Safe for Class I, II, III, Division 1, Groups A, B, C, D, E, F, G; Non-incendive for Class I, Division 2, Groups A, B, C, D. Suitable for indoor and outdoor locations NEMA 4x. Ambient temperature limits: -50 to 80 °C when installed in accordance with Rosemount Drawing 00644-0009. FM Entity Parameters: See installation drawing 00644-0009. Temperature Code T5 ( $T_{amb} = 80\text{ °C}$ ) (T6 ( $T_{amb} = 40\text{ °C}$ ))

**Special Conditions for Safe Use (X):**

When the output of the associated apparatus does not exceed  $P_o = 0.6$  Watts, the temperature code is T6 ( $T_{amb} = 50\text{ °C}$ )

- K5** Combination of E5 and I5

---

**NOTE:**

Approval K5 is only available with Model 644H option codes J5 and J6.

---

**Canadian Standards Association (CSA) Approvals**

- I6** Intrinsically safe for Class I, Division 1, Groups A, B, C, and D when connected in accordance with Rosemount drawing 00644-1064
- C6** Combination of I6 and the following: Explosion-Proof for Class I, Division 1, Groups B, C, and D. Dust-ignition proof for Class II, Division 1, Groups E, F, and G. Dust-ignition proof for Class III, Division 1 hazardous locations when installed in accordance with Rosemount Drawing 00644-1059. Suitable for Class I, Division 2, Groups A, B, C, and D.

---

**NOTE:**

Approval C6 is only available with Model 644H option code J6.

---

**CENELEC/KEMA Approvals**

- ED** ATEX Category II 2 G Certification number KEMA 99ATEX8715  
 Flameproof (Zone 1) (Model 644H only)  
 EEx d IIC T6 ( $T_{amb} = -40$  to  $65\text{ }^{\circ}\text{C}$ ).  
 Requires a connection head or Universal head.

**CENELEC/British Approvals Service for Electrical Equipment in Flammable Atmospheres (BASEEFA) Approvals**

- I1** ATEX Category II 1 G Certification number BAS00ATEX1033X  
 Intrinsically Safe Operation (Zones 0)  
 EExia IIC T6 ( $T_{amb} = -60$  to  $40\text{ }^{\circ}\text{C}$ )  
 EExia IIC T5 ( $T_{amb} = -60$  to  $50\text{ }^{\circ}\text{C}$ )  
 EExia IIC T5 ( $T_{amb} = -60$  to  $40\text{ }^{\circ}\text{C}$ )  
 EExia IIC T4 ( $T_{amb} = -60$  to  $80\text{ }^{\circ}\text{C}$ )  
 Entity Parameters: See appropriate approval certificate

**Special Conditions for Safe Use (X):**

The apparatus must be installed in an enclosure which affords it a degree of protection of at least IP20. Non-metallic enclosures must have a surface resistance of less than  $1\text{G}\Omega$ , light alloy or zirconium enclosures must be protected from impact and friction when installed.

- N1** ATEX Category II 3 G Certification number BAS00ATEX3145  
 Type 'nL' Operation Non-Incendive Approval (Zone 2 only)  
 EEx nL IIC T5 ( $T_{amb} = -40$  to  $70\text{ }^{\circ}\text{C}$ )  
 (Type 'nL' certification is only available as a complete assembly with the Rosemount universal head, thermometer, and thermowell.)

**Standard Australia Quality Assurance Service (SAA)****NOTE**

Consult factory for SAA availability.

- I7** Intrinsic Safety,  
 Ex ia IIC T5 ( $T_{amb} = -60$  to  $80\text{ }^{\circ}\text{C}$ )  
 Ex ia IIC T4 ( $T_{amb} = -60$  to  $80\text{ }^{\circ}\text{C}$ )  
 Entity Parameters: See appropriate approval certificate

**Special Conditions for Safe Use (X):**

The transmitter must be installed so that its external terminals and communication pins are protected to at least IP20.

- N7** Type n Approval,  
Ex n IIC T6 ( $T_{amb} = -40$  to  $60\text{ }^{\circ}\text{C}$ )

**Special Conditions for Safe Use (X):**

The assembly must be installed such that its external terminals and communication pins are protected to at least the requirements of IP54.

- E7** Flameproof Approval (Model 644H only)  
Ex d IIC T6 ( $T_{amb} = 65\text{ }^{\circ}\text{C}$ )

**NOTE:**




Flameproof certification is only available as a complete assembly with Rosemount universal head – option codes J5 or J6.

**Gostandart**

Tested and approved by the Russian Metrological Institute GOSTANDART.


**EUROPEAN ATEX DIRECTIVE INFORMATION.**

Rosemount Model 644H and 644R Temperature Transmitters that have the following labels attached have been certified to comply with Directive 94/9/EC of the European Parliament and the Council as published in the Official Journal of the European Communities No. L 100/1 on 19-April-1994.




---

The following information is provided as part of the labeling of the transmitter:


- Name and address of the manufacturer (Rosemount U.S.A)
-  0600
- Complete model number
- The serial number of the device
- Year of construction
- Marking for explosion protection:

BASEEFA ATEX Certification Number: BAS00ATEX1033X

 II 1 G

EEx ia IIC T<sub>4</sub>/T<sub>5</sub>/T<sub>6</sub>

or KEMA ATEX Certification Number: KEMA 99ATEX8715

 II 2 G

EEx d IIC T<sub>6</sub>

## INSTALLATION DRAWINGS

The installation guidelines presented by the drawings must be followed in order to maintain certified ratings for installed transmitters.

Rosemount Drawing 00644-1064, 1 Sheet,  
Canadian Standards Association Intrinsic Safety Installation Drawing

Rosemount Drawing 00644-1059, 1 Sheet;  
Canadian Standards Association Explosion-Proof Installation Drawing

Rosemount Drawing 00644-0009, 1 Sheet  
Factory Mutual Intrinsic Safety Installation Drawing

Rosemount Drawing 00644-1049, 1 Sheet;  
Factory Mutual Explosion-proof Installation Drawing

---

### IMPORTANT

Once a device labeled with multiple approval types is installed, it should not be reinstalled using any of the other labeled approval types. To ensure this, the approval label should be permanently marked to distinguish the used from the unused approval type(s).

---



Figure B-3. Canadian Standards Association (CSA) Intrinsic Safety Installation Drawing 00644-1064, Rev. AB








Figure B-4. Canadian Standards Association (CSA) Explosion-Proof Installation Drawing 00644-1059, Rev. AC




644-1059A01A

Figure B-5. Factory Mutual (FM) Intrinsic Safety Installation Drawing 00644-0009, Rev. AA



644-0009A01A

B-9





Rosemount Inc

---

**C****Model 644 and 244E Manual  
Supplement**

---

Old Transmitter .....	page C-2
New Transmitter .....	page C-4
Specifications .....	page C-6



---

This manual supplement is intended to indicate the primary differences between the old and new Models 644 and 244E. These differences are as follows:

- Transmitter design
- Sensor Wiring Diagrams
- Special Mounting Considerations
- Specifications






OLD

Transmitter Design

Models 644H and 244EH	Models 644R and 244ER
<p>Two Mounting Holes</p> 	

644-01260B01B, 1105E01B,  
1101A01A

Sensor Wiring Diagrams




Models 644 and 244E				
				
2-wire RTD and $\Omega$	3-wire <sup>*</sup> RTD and $\Omega$	RTD with <sup>**</sup> Comp. Loop	4-wire <sup>**</sup> RTD and $\Omega$	T/C and mV

644-0000B01B

<sup>\*</sup> Rosemount Inc. provides 4-wire sensors for all single element RTDs. You can use these RTDs in 3-wire configurations by leaving the unneeded leads disconnected and insulated with electrical tape.

<sup>\*\*</sup> The transmitters must be configured for a 3-wire RTD in order to recognize an RTD with a compensation loop.

Special Mounting Considerations


Mounting a Model 644H to a DIN Rail	G-Rail	Top Hat Rail
<div>1. Assemble the appropriate rail clip (part number 00644-5301-0001).</div> <div>2. Attach the transmitter to a rail or panel.</div> <div>3. Attach the thermowell to the pipe or process container wall and attach sufficient lengths of sensor lead wire. Tighten the connection head cover.</div> <div>4. Run the sensor lead wires from to the sensor and set the transmitter failure mode switch.</div> <div>5. Attach the sensor and power leads to the transmitter.</div>		
Use with an Existing Threaded Sensor Connection Head		
<div>To mount the Models 644H and 244EH in an existing L1 connection head, assemble the Model 644H retrofit kit (part number 00644-5321-0001) to the transmitter as shown. Then mount the assembly in the connection head.</div>	<div><p>Kit includes replacement bracket and screw</p></div>	

644-5301B01B,D01B


644-644-5051A01A

**NEW**

## Transmitter Design



## Sensor Wiring Diagrams





\* Rosemount Inc. provides 4-wire sensors for all single element RTDs. You can use these RTDs in 3-wire configurations by leaving the unneeded leads disconnected and insulated with electrical tape.

\*\* The transmitters must be configured for a 3-wire RTD in order to recognize an RTD with a compensation loop.



Special Mounting Considerations

Use with an Existing DIN Plate Style Sensor	
<div>1. Secure the bottom of the mounting screw sleeve with pliers. Remove the mounting screws and springs.</div> <div>2. Once the springs are removed, use the new transmitter mounting screws to assembly the transmitter to the DIN plate and connection head. (Optional snap rings (part number 00644-4432-0001) are available to ease installation o an existing DIN plate style sensor.)</div>	<div></div> <div>SENSORS-0000A02B</div>
Use with an Existing Threaded Sensor Connection Head	
<div>To mount the new Models 644H or 244EH to an existing threaded sensor connection head (former option code L1), order the Models 644H and 244EH retrofit kit (part number 00644-5321-0010). The fit includes a new mounting bracket and all associated hardware necessary to facilitate the installation of the Models 644H and 244EH into the existing head.</div>	<div></div> <div>644-644-5321A01A,</div>

HART Communicator (Model 644 only)

To guarantee proper transmitter functionality and communication, your Model 275 HART Communicator should contain device revision Dev v5 DD v2 or higher. To check software device revision,

1. Turn on the communicator.
2. Select *1 Off-line, 1 New Configuration, Rosemount, 644 Temp*

If you do not have this device revision, contact your local Rosemount representative for information on receiving an upgrade.

## SPECIFICATIONS

Old					New		
BASEFFA <sup>(1)</sup> Intrinsically Safe Installation Entity Parameters:							
Power Loop	U <sub>max:in</sub>	30 V dc			30 V dc		
	I <sub>max:in</sub>	200 mA			200 mA		
	W <sub>max:in</sub>	1.0 W			1.0 W	0.67 W	
		<ul style="list-style-type: none"><li>• T5 (− 40 ≤ T<sub>a</sub> ≤ 40 °C)</li><li>• T4 (− 40 ≤ T<sub>a</sub> ≤ 80 °C)</li></ul>			<ul style="list-style-type: none"><li>• T5 (− 60 ≤ T<sub>a</sub> ≤ 40 °C)</li><li>• T6 (− 40 ≤ T<sub>a</sub> ≤ 40 °C)</li></ul>	<ul style="list-style-type: none"><li>• T4 (− 40 ≤ T<sub>a</sub> ≤ 80 °C)</li><li>• T5 (− 60 ≤ T<sub>a</sub> ≤ 50 °C)</li></ul>	
	C <sub>eq</sub>	13.4 nF			10 nF		
	L <sub>i</sub>	0 μH			0 μH		
Sensor	U <sub>o</sub>	24.2 V dc			13.6 V dc		
	I <sub>o</sub>	33 mA			80 mA		
	P <sub>o</sub>	0.2 W			0.08 W		
Cable Load		IIC	IIB	IIA	IIC	IIB	IIA
	C <sub>o</sub> (μF)	0.2	0.6	1.6	0.7	5.1	18.5
	L <sub>o</sub> (mH)	31	93	248	5	23	48
<i>Special Conditions for Safe Use: The apparatus must be installed such that its external terminals and the communication pins are protected to at least IP20.</i>					<i>Special Conditions for Safe Use: The apparatus must be installed in an enclosure which affords it a degree of protection of at least IP20. Non-metallic enclosures must have a surface resistance of less than 1 GΩ, light alloy or zirconium enclosures must be protected from impact and friction when installed.</i>		

**CSA<sup>(2)</sup> Intrinsically Safe Installation Connection Parameters:**

Class I Div. 1 Groups A, B, C, and D	T5 ( $-50 \leq T_a \leq 60^\circ\text{C}$ )	<ul style="list-style-type: none"> <li>• 30 V or less, 330 ohms or more</li> <li>• 28 V or less, 300 ohms or more</li> <li>• 25 V or less, 200 ohms or more</li> <li>• 22 V or less, 180 ohms or more</li> </ul>	T6 ( $-50 \leq T_a \leq 40^\circ\text{C}$ )	<ul style="list-style-type: none"> <li>• 30 V or less, 340 ohms or more</li> <li>• 28 V or less, 300 ohms or more</li> <li>• 25 V or less, 240 ohms or more</li> <li>• 22 V or less, 190 ohms or more</li> </ul>
			T5 ( $-50 \leq T_a \leq 60^\circ\text{C}$ )	
Class I Div. 1 Groups C and D		<ul style="list-style-type: none"> <li>• 30 V or less, 150 ohms or more</li> </ul>	T4 ( $-50 \leq T_a \leq 80^\circ\text{C}$ )	<ul style="list-style-type: none"> <li>• 30 V or less, 330 ohms or more</li> <li>• 28 V or less, 250 ohms or more</li> <li>• 25 V or less, 240 ohms or more</li> <li>• 22 V or less, 190 ohms or more</li> </ul>
			T4 ( $-50 \leq T_a \leq 80^\circ\text{C}$ )	

**Factory Mutual<sup>(3)</sup> Intrinsically Safe Installation Entity Parameters:**

Power Loop	$V_i$	30 V dc	30 V dc	
	$I_i$	250 mA	240 mA	
	$P_i$	1.0 W	1.0 W	0.67 W
		<ul style="list-style-type: none"> <li>• T5 (<math>-50 \leq T_a \leq 60^\circ\text{C}</math>)</li> </ul>	<ul style="list-style-type: none"> <li>• T5 (<math>-50 \leq T_a \leq 40^\circ\text{C}</math>)</li> <li>• T4 (<math>-50 \leq T_a \leq 80^\circ\text{C}</math>)</li> </ul>	<ul style="list-style-type: none"> <li>• T6 (<math>-50 \leq T_a \leq 40^\circ\text{C}</math>)</li> <li>• T5 (<math>-50 \leq T_a \leq 50^\circ\text{C}</math>)</li> </ul>
	$C_i$	0.008 $\mu\text{F}$	0.010 $\mu\text{F}$	
	$L_i$	0 $\mu\text{H}$	0 $\mu\text{H}$	
Sensor	$V_t$	10.7 V dc	13.6 V dc	
	$I_t$	15.3 mA	22 mA	
	$P_o$	0.04 W	0.11 W	
	$C_a$	2.23 $\mu\text{F}$	0.8 $\mu\text{F}$	
	$L_a$	140 mH	60.0 mH	

(1) For more information see approval certificate. Old: Model 644H: 95C2010X, Model 244E: 95C2019X; New: Model 644H: BAS00ATEX1033X, Model 244E: BAS00ATEX1034X

(2) For more information see Rosemount drawing 00644-1040, Rev. B (old) and 00644-1064, Rev AA (new).

(3) For more information see Rosemount drawing 00644-1056, Rev. B (old) and 00644-0009, Rev AA (new)



Rosemount Inc

---